


Ersatzteilliste_HPI-Motor



1.	10569929	Motor	
2.	10569921	Ventil	
3.	10539823	Schraube	
4.	10569916	Flansch	

Ersatzteilliste_HPI-Motor

5.	10569917	Vorsatzlager	
6.	10539975	Schraube	
7.	10539908	Mutter	
8.	10539853	Schraube	
9.	10539985	Scheibe	
10.	10529768	Hülse	
11.	10569918	Büchse	
12.	10549984	Wellendichtring	