

DISTRIBUTEUR D'ENGRAIS X12-50

FERTILISER SPREADER X12-50





DUNGERSTREUER X12-50

РАЗБРАСЫВАТЕЛЬ УДОБРЕНИЙ X12-50

RÉF : 400 712-00 - EU/UX




PALE EV - BLADES EV - WURSCHAUFEL EV - ЛОПАТКИ EV










EV 12-18

1	2	3	4
			
TRCC 8 x 16	M 10 N	H8	M 8 N
			L 6 N
			H6
			TRCC 8 x 25
			M 10 N
			H8
			TRCC 8 x 30
			H8




EV 18-28

1	2	3	4
			
TRCC 8 x 16	M 10 N	H8	TRCC 6 x 15
			
M 8 N	L 6 N	H6	TRCC 8 x 25
			
M 10 N	H8	TRCC 8 x 30	H8




EV 24-36

1			2				3			4	
TRCC 8 x 16	M 10 N	H8	TRCC 6 x 15	M 8 N	L 6 N	H6	TRCC 8 x 25	M 10 N	H8	TRCC 8 x 30	H8



EV 32-44

1	2	3	4
			
TRCC 8 x 16	M 10 N	H8	TRCC 6 x 15
			
M 8 N	L 6 N	H6	TRCC 8 x 25
			
M 10 N	H8	TRCC 8 x 30	H8



EV 40-50	1			2				3			4	
	TRCC 8 x 16	M 10 N	H8	TRCC 6 x 15	M 8 N	L 6 N	H6	TRCC 8 x 25	M 10 N	H8	TRCC 8 x 30	H8

