
























S3K80/4E

		Code	Description	Qty
1		209199A/A	Bearing support	1
2		204470B	Magnetic plug	1
4		203370P	Breather plug	1
5		203405P	Oil dipstick	1
6		3VTE002	Screw	8
7		203903A/A	Cover	1
8		203903A/A	Cover	1
9		203355F	Gasket	2
10		209536H	Shaft	1
11		3CU021	Ball bearing	1
12		3AT007	Seal ring	1
13		3CU021	Ball bearing	1
14		3AT007	Seal ring	1
15		3AP003	Seal ring	1
16		3LI016	Key	1
17		3LI012	Key	1
18		217274N	Self-locking nut	1
19		203954A	Pump body	1
20		3VP005T	Stud bolt	2
21		3DEA010T	Nut	2

S3K80/4E

		Code	Description	Qty
22		3VP021	Stud bolt	4
23		3DEA014Z	Nut	4
24		3VP041	Tie rod	8
25		3DEA012Z	Nut	6
26		203987A	Wear ring	1
27		3NO019	Plug	2
28		214113F	Stuffing-box ring	6
29		201007C	Stuffing-box flange	1
30		203951A00	Impeller	1
31		203953A/1A	Suction cover	1
32		203987A	Wear ring	1
33		3LI011	Key	3
34		203947A/A	Diffuser	3
35		203987A	Wear ring	6
36		203950A00	Impeller	2
37		203986T	Spacer	3
38		203952A	Diffuser shell	3
39		3NO019	Plug	3
40		3OR069	O-Ring	3
41		209011Q	Bush	1

S3K80/4E

		Code	Description	Qty
42		209537Q	Bush	1
43		201691C	Bush	1
44		205534N	Foot	1
45		206715D	Washer	1
46		3DEM012Z	Nut	2
47		203950A00	Impeller	1
49		218271F	Gasket	1
50		209538I	Spacer	1
51		204461N	Reduction flange	1
52		3VTCEI008	Screw	4