

## **Maintenance Plan - Greyhound**

Version: 150 LS-AS-HS-4WD

200 LS-AS Volume: 15m<sup>3</sup>- 20m<sup>3</sup>

DEUTZ engine, 6 cylinders, 190 HP, EMR3

Check / Adjust

Replace

▲ Clean

**X** Grease

			Working hour interval							
			After the first		Every		After			
	CODE	Q.TY	10	100	8	50	250	500	1000	2000
ENGINE OIL (15W40)	98000004	14 I	•			•		-		
ENGINE OIL FILTER (01174421)	99003026	1						-		
DIESEL FUEL PREFILTER (04291642)	99003040	1					<b>A</b>		•	
1« DIESEL FUEL PREFILTER (04504438)	99012016	1					<b>A</b>			
DIESEL FUEL FILTER (01182672)	99003039	2								
INTERNAL AIR FILTER CARTRIDGE (ST12-11390)	99011968	1			<b>A</b>			-		
AIR FILTER CARTRIDGE (CH12-11388)	99011969	1			<b>A</b>			-		
EXTERNAL CABIN AIR FILTER (AP6137)	98405102	1			<b>A</b>					
INTERNAL CABIN AIR FILTER	98405265	1			<b>A</b>			-		
COOLANT (Eni Antifreeze Bike S)	98400553	25 I	● ■ 2000 hours or 2 years							
HYDRAULIC OIL FILTER CARTRIDGE	99011009	1								
HYDRAULIC OIL (Agip Oso 46)	98000000	85 I	•			•				•
AUGER GEARBOX OIL (AGIP BLASIA 220)	98000001	6.7 I	•			•				
TRANSMISSION OIL SI372 (Agip Blasia 220)	98000001	3.4	•	-		•			•	
MILLING CUTTER GEARBOX OIL (Agip Blasia 220)	98000001	1.5	•							
WHEEL GEARBOX OIL AS (Agip Blasia 220)	98000001	0.8+0.81	•							
WHEEL GEARBOX OIL HS (Agip Rotra MP 85W140)	98000019	1.7+1.7	•	•						
BRAKE OIL (Agip DOT4)	98000012	0.51	• ■ 2000 hou			hours or	ours or 2 years			
AUGER BLADE KIT		1	•				•			
MILLING CUTTER BLADE KIT		1	•				•			
WEAR - LOCKING SCREW AND NUTS AUGER KNIVES			•				•			
WHEEL NUT TIGHTENING			•	•			•			
OVERALL BOLT AND NUT TIGHTENING			•				•			
2« LEAK CHECKING FROM HYDRAULIC SYSTEM PIPES HYDRAULIC PIPE AND FITTING TIGHTENING			•			•				
AIR CONDITIONER BELT	i							•		
ENGINE BELT	1							•		
INTAKE PIPING	İ		•					•		
BATTERY	1							•		
CLUTCH	i				Αι	itomatic	registrat	ion		
SUSPENSIONS	1		•					•		
3« RADIATOR CLEANING	İ				<b>A</b>					
LOADING CONVEYOR	1		•		<b>A</b>	•				
UNLOADING CONVEYOR	1		•		<b>A</b>	•				
3« ENGINE COMPARTMENT CLEANING	1					<b>A</b>				
FRONT WHEELS (315/70 R22.5)	99100166	2					●8 bar			
REAR WHEELS (445/65 R22.5)	99100151	4					●8 bar			
UNLOADING DOOR GUIDES							х			
CARDAN SHAFT CROSSES						х				
BEARINGS / BUSHINGS	Spare o	Automatic central greasing NLGI-0								
CYLINDERS AND PIVOT PINS	98400890	Automatic central greasing NLGI-0								
OTHER NON-AUTOMATED POINTS							х			

## NOTES:

- 1« Only applies to engines delivered starting from 2011: check the code in the cartridge.
- 2« Periodically check the rubber hoses: if visual inspection enables detection of evident signs od deterioration, replace them.
- 3« Thoroughly clean with air to eliminate dust and deposits of foreign matter.

N.B. THE QUANTITIES OF OIL REPORTED IN THE TABLE ARE APPROXIMATIVE.

THE PERSON WHO WILL EXECUTE THE MAINTENANCE, WILL BE RESPONSABLE AND HAS TO VERIFY THE EXACT QUANTITY OF OIL APPLYING TO THE CHECKPOINTS OF THE MAXIMUM LEVEL WHICH ARE MENTIONED IN THE USER & MAINTENANACE MANUAL OF THE MACHINE