


MODELO **AR** *MODEL* **MODELE**




INSTRUCCIONES PARA EL MANEJO Y CONSERVACION
INSTRUCTIONS FOR THE OPERATION USE AND MAINTENANCE
MANUEL D'ENTRETIEN ET D'UTILISATION


AGRATOR, S.A.


DESPIECE AR - AR SPARE PARTS CATALOGUE - AR CATALOGUE PIÉCES


Apartado, 316 — Télex 35428 — Teléfonos 265600 - 265611 - 265622 - **VITORIA (ESPAÑA)**
P.O. Box, 316 — Télex 35428 — Telephone 265600 - 265611 - 265622 - **VITORIA (SPAIN)**
B. P., 316 — Telex 35428 — Téléphone 265600 - 265611 - 265622 - **VITORIA (ESPAGNE)**

LAMINA 1
DRAWING N° 1
PLANCHE N° 1









VR-Bak mit dem.

LAMINA 5
DRAWING N° 5
PLANCHE N° 5

