


F34K100-120/SE



F34K100-120/5E

	Code	Description	Qty
1	2073480/A	Flange	1
12	3LI074	Key	1
13	2073499A/A	Bearing support	1
14	3VP024	Stud bolt	4
15	3DEA020	Nut	4
16	3RE020T	Washer	4
17	204470B	Magnetic plug	1
18	207475B	Breather plug	1
19	207355A/A	Cover	1
20	3VTE004	Screw	4
22	207357F	Gasket	1
23	207356A/A	Cover	1
24	3VTE004	Screw	4
26	204086F	Gasket	1
27	208347H05	Shaft	1
28	3AT003	Seal ring	1
29	3GAN060Z	Self-locking ring nut	1
31	3CU055	Ball bearing	1
32	3CU056	Roller bearing	1
33	3AT012	Seal ring	1

F34K100-120/5E

	Code	Description	Qty
34	3AP006	Seal ring	1
35	214893T/A	Twinner stuffing-box flange	1
36	214110F	Stuffing-box ring	6
37	3VP009T	Stud bolt	2
38	3DEA010T	Nut	2
39	207305T	Bush	1
40	3OR026	O-Ring	1
41	207309T	Bush	1
43	207300A	Pump body	1
44	3VP024	Stud bolt	4
45	3DEA020	Nut	4
46	3RA004	Washer	1
47	3NO019	Plug	2
48	3RA004	Washer	2
49	3NO019	Plug	3
50	3RA004	Washer	3
51	207302A/A	Wear ring	1
52	207297A/A	Diffuser ring	5
53	208973A	Diffuser shell	4
54	3OR027	O-Ring	5

rovatti pompe

F34K100-120/5E

	Code	Description	Qty
55	3N0019	Plug	8
56	3RA004	Washer	8
57	207302A/A	Wear ring	8
58	207293A00	Impeller	4
59	3L1013	Key	1
60	3L1023	Key	3
61	207303T	Spacer	4
62	207294A	Suction cover	1
63	207411A	Wear ring	1
64	207410A00	Impeller	1
65	3L1026	Key	1
66	207304T	Spacer	1
67	3L1001	Key	1
68	207306T	Bush	1
69	207307C	Bush	1
70	207310I	Washer	1
71	3DA016Z	Self-locking nut	1
72	3V/P057	Tie rod	2
73	3DEA016Z	Nut	2
74	3RB016TA	Washer	2

rovatti pompe

F34K100-120/5E

	Code	Description	Qty
75	3VP066	Tie rod	6
76	3DEA016Z	Nut	12
77	3RB016TA	Washer	12
78	207317N	Foot	1
79	3VTE004	Screw	2
80	3RE010Z	Washer	2
81	208969C	Bush	4
82	212446P	Protection	1
83	3VTE115Z	Screw	3
84	3RP001Z	Washer	3
86	3RA005	Washer	1
87	3NO009	Plug	1