

SPARE PART LIST

**TP1230IN
TURBO JET SUPER 12**

**HYDRAYLIC DRIVE
STANDARD**

**SEEDER+ CONTROL UNIT
VERSION 2024**



Technik-Plus

Company „Technik-Plus Sämaschinen e.U.“
Industrieparkstrasse 6-8
8480 Mureck
AUSTRIA

Tel: +43 347221120

E-Mail: technik-plus@technik-plus.eu

E-Mail: office@technik-plus.eu



www.technik-plus.eu


SPARE PART LIST


TURBO JET SUPER 12 TP1230IN


HYDRAULIC DRIVE STANDARD





Nr	Product name	Spare part number	Picture
01	Frame (dosing unit)	10529919	
02	Lamella unit	10529824	
03	Washer 6xM5	10537621	
04	Geared washer M8,4	10537634	
05	Seed roll cover	10528496	
06	Frame for window	10529821	
07	Lock ring 10x1	10539945	
08	Washer 20 x 8,5 x 2 A2	10539731	

Nr	Product name	Spare part number	Picture
09	Gear S=10, DM=10	10519955	
10	Plastic bearing for agitator I-DM=10,2; A-DM=19,7; s=7	10519808	
11	Distance bush I-DM: 10,1 A-DM: 20, S=12	10529812	
12	Splint 3x40 for agitator A2	10539923	
13	Agitator TP12	10619913	
14	Plastic bearing for seed roll I-DM:20; A-DM:42,5 S:12	10519812	
15	Gear with inlet hexagon	10519839	
16	Lock ring 18x1,2	10539824	

Nr	Product name	Spare part number	Picture
17	Metal seed roll	10529923	
18	Standard Seed roll	10519831	
19	Star knob	10539885	
20	Bottom flap withhout TP12 stipe (Stainless steel)	10528495	
21	Bottom flap TP12 (plastic)	10519562	
22	Hexagon axle with lever TP12	10529781	
23	Bearing bracket TJS for seed roll TP12	10529994	
24	Acrylic glass 305 x 99	10519985	

Nr	Product name	Spare part number	Picture
25	Screw M4 x 12 A2	10539801	
26	Lock nut M4 A2	10539694	
27	Thrust washer M8	10539993	
28	Thrust washer M8 x12 A2	10539806	
29	Washer galvanized M20 for Seed roll	10539675	
30	Locking pin	10529634	
31	Hexagon wheel TP12	10529826	
32	Bottom Flap with stipe stainless steel: 5,10,15 and 3,5mm	10529312	

Nr	Product name	Spare part number	Picture
33	Agitator cover	10529962	
34	Lock nut M8 galvanized for Agitator cover	10539905	
35	Washer 8,4 x 24 x 2 A2	10537621	
36	Geared washer M8 A2	10539741	
37	Star knob M8 galvanized DM40	10539901	
38	Washer 20x28x1 A2	10537627	
39	Bracket for brush	10528493	
40	Brush	10010017	

36	Product name	Spare part number	Picture
41	Screw for brush M5x10 Niro (A2)	10539673	
42	Lock nut M5 (Niro)A2	10539917	
43	Bottom cup to twist of	10529492	
44	Pipe register TP12/DM30mm	10529190	


SPARE PART LIST




TP1230IN
TURBO JET SUPER 12


HYDRAULIC DRIVE STANDARD




Nr	Product name	Spare part number	Picture
1	Valve DM380mm	10529958	
2	Screw connection	10539876	

Nr	Product name	Spare part number	Picture
3	Nut 17x3/8	10529960	
4	Cable connector	10539990	
5	Spring ADM=26,5, H=14; S=1,8 W=3 NIRO	10539978	
6	Hopper trapeze small 300 x 120	10529809	
7	Hopper trapeze big 460 x 120	10529810	
8	Hexagon screw M6x20	10539981	
9	Thrust washer M6	10539984	
10	Distance washer M6,5x3x17	10539985	

Nr	Product name	Spare part number	Picture
11	Lock nut M10	10539908	
12	Motor plate	10528579	
13	Counting wheel	10529954	
14	Screw M5x10	10539742	
15	Cover for Blower wheel	10529817	
16	Hopper cone	10529815	
17	Spreader plate DM 30mm Spreader plate DM 25mm	10529130 10529196	
18	Rubber seal	10579909	


Nr	Product name	Spare part number	Picture
19	Seed roll motor	10569909	
20	Cover seed roll motor	10529811	
21	End spice	10539994	
22	washer	10537640	
23	Screw M10x25	10539909	
24	Lock nut M10	10539908	
25	Distance bush L=77; ADM=13 Distance bush L=63mm, ADM=14	10529804 10529992	
26	Ring to cover	10519947	



Nr	Product name	Spare part number	Picture
27	Cover	10519948	
28	Sensor holder	10529124	
29	Hopper 300-lit with cover	10519916	
30	Screw	10537619	
31	Locking washer	10539993	
32	Screw	10537637	







SPARE PART LIST

TP1230IN TURBO JET SUPER 12

HYDRAULIC DRIVE STANDARD




Nr	Product name	Spare part name	Picture
1	Hopper 130-lit with cover	10519904	
2	Hopper 200-lit with cover	10519829	

Nr	Product name	Spare part number	Picture
3	Hopper 300-lit with cover	10519916	
4	Hopper 400-lit with cover	10519917	
5	Hopper 500-lit with cover	10519918	
6	Hopper 800-lit with cover	10519988	
7	Hopper 1.200 with cover and hopper cone	10519555	
8	Hopper 1.500 with cover and hopper cone	10519807	
9			
10			


SPARE PART LIST

TURBO JET SUPER 12
TP1230IN

HYDRAULIC DRIVE
STANDARD



Nr	Product name	Spare part number	Picture
1	Monitor SEEDER+	10589956	
2	Socket	10519811	

Nr	Product name	Spare part number	Picture
03	13-pin connector	10519697	
04	4-pin plug	10519958	
05	Socket 4-pin	10519959	
06	Battery cable length: 3,5m	10619960	
07	Control box including circuit board	10589953	
08	13-pin socket	10519698	
09	Circuit board from control box	10549779	
10	Cable screw PG7	10519844	


Nr	Product name	Spare part number	Picture
11	Sensor cable length: 10 m	10549906	
12	Sensor DM: 30mm	10639902	
13	Sensor DM: 18mm	10639901	
14	Sensor with cable	10619936	
15	Cable with plug	10549815	
16	Blade fuse holder with 6mm ² cable	10539738	
17	Cable SET for Seeder blower drive (hydraulic)	10619793	
18	Cable screw PG9	10519963	

Nr	Product name	Spare part number	Picture
19	Fuse 15A blue	10539863	
20	Fuse 2A Gray	10539670	
21	Fuse 20A Yellow	10537648	

SPARE PART LIST


TURBO JET SUPER 12
TP1230IN

HYDRAULIC DRIVEA
STANDARD



Nr	Product name	Spare part number	Picture
1	Valve	10569942	
2	Screw connection	10549948	

Nr	Product name	Spare part number	Picture
3	Screw connection	10549948	
4	T-screw connection	10549932	
5	Hexagonal screw M6x50 galvanized	10539884	
6	Locking washer	10539984	
7	Washer	10539985	
8	Hydraulic line	10549987	
9	Screw connection	10549925	
10	Einschraubung	10549998	
11	Protractor screw connection	10549939	

Nr	Product name	Spare part number	picture
12	Hydraulic line	10549785	
13	Hydraulic line	10549787	
14	Union nut	10549949	
15	Cutting ring	10549950	
16	T-screw connection	10549941	
17	Check valve	10556943	
18	Hydraulic pipe	10549954	
19	Hexagon socket screw with countersunk head M10x90Vz	10539975	
20	Stop nut M10 galvanized	10539908	

Nr	Product name	Spare part number	Picture
21	washer	10539890	
22	Wedge for front bearing	10529225	
23	Attachment bearing	10569917	
24	gear	10569918	
25	Hydraulic motor	10569958	
26	pump flange	10549812	
27	screw connection	10549924	
28	Cross screw connection	10529224	

Nr	Product name	Spare part number	picture
29	Cross screw connection	10549806	

